

**FCC Part 15 C Notice**

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions :

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**INDUSTRY CANADA NOTICE: CANADA ONLY.**

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

**IMPORTANT! REGISTER YOUR DRONE**

The U.S. Department of Transportation's Federal Aviation Administration (FAA) announced a streamlined and user-friendly web-based aircraft registration process for owners of small unmanned aircraft (UAS) weighing more than 0.55 pounds (250 grams) and less than 55 pounds (approx. 25 kilograms) including payloads such as on-board cameras.

Owners can get more info and may register through a web-based system at [www.faa.gov/uas/registration](http://www.faa.gov/uas/registration)

**CAN ICES-3 (B)/NMB-3(B)**

This product meets the applicable Innovation, Science and Economic Development Canada technical specifications.

Ce produit répond aux spécifications techniques pertinentes d'Innovation, Science et Développement économique applicables.




Requires Speed Class 6 or higher microSD or microSDHC card (not included)  
microSDHC Logo is a trademark of SD-3C, LLC.

©2017 Rooftop Brands™ All rights reserved.  
Tel: + (1) 949-566-9573 • [www.propelrc.com](http://www.propelrc.com)

Made in China  
V3


**HD VIDEO DRONE+ WiFi**  
HD Quadcopter with Streaming Video and  
Altitude Stabilization Technology



**INSTRUCTION BOOKLET**

**WARNING:** Never leave product charging unattended for extended periods of time. Always disconnect the battery from charger immediately after the battery is fully charged. Please refer to enclosed safety instructions.

**PACKAGE CONTAINS:**



Colors and styles may vary slightly.



PROPEL

## TABLE OF CONTENTS

Features . . . . .	2
Remote Control Battery Installation . . . . .	2
Charging the HD Video Drone+WiFi's Li-Poly Battery . . . . .	2
HD Video Drone+WiFi Battery Installation . . . . .	2
HD Video Drone+WiFi Diagram . . . . .	3
Remote Control Diagram . . . . .	3
Flight Preparation . . . . .	4
Syncing Your HD Video Drone+WiFi . . . . .	4
Now You Are Ready To Fly . . . . .	5
Recognizing The Front & Rear Of The HD Video Drone+WiFi . . . . .	5
How to Start/Stop Rotors . . . . .	5
Speed Select Button . . . . .	5
Auto Land Button . . . . .	5
Adjusting the Trim Settings . . . . .	5
3 Channel VS 4 Channel Flying . . . . .	6
3 Channel Flight Control . . . . .	6
4 Channel Flight Control . . . . .	7
Flight Practice . . . . .	7
Adjusting The Trim . . . . .	8
Calibrating The HD Video Drone+WiFi . . . . .	9
How To Perform 360° Stunt Rolls . . . . .	10
Using Your On-Board Camera . . . . .	11
Removing Your microSDHC card . . . . .	12
Downloading and Clearing Space on Your microSDHC card . . . . .	12
Troubleshooting Your HD Video Drone+WiFi . . . . .	13
Replacing The Propeller Blades . . . . .	13
Warnings . . . . .	14
Battery Warnings . . . . .	14
Care and Maintenance . . . . .	14
FCC Information . . . . .	15


Thank you for purchasing the HD Video Drone+WiFi 2.4 Ghz Quadcopter. Please read this instruction booklet as it contains valuable information on how to properly fly and care for your HD Video Drone+WiFi.

## FEATURES

- Flight range up to 400 feet!
- Six axis gyro for extremely stable flight and maneuverability
- Switch-blade technology allows you to operate in 3ch or 4ch modes for beginner to advanced pilots.
- Push button 360° aerial stunts
- On-board camera records high-definition videos and still photos
- Streams video to your mobile device
- Air pressure sensors lock flight altitude for stable video footage
- Automatically lands with the push of a button
- Additional replacement parts included

## REMOTE CONTROL BATTERY INSTALLATION



1. Slide off the battery cover from the back of the controller.
2. Install 6 "AA" alkaline batteries into the controller as shown in diagram A.
3. Replace the battery cover.
4. Turn over the controller and turn the on/off switch to the on position. If the LCD screen turns on you have installed your batteries properly.



## CHARGING THE HD VIDEO DRONE+WiFi'S LI-POLY BATTERY

1. Insert the battery to the charger as shown (see illustration B).
2. Next, connect the USB charging cord to your computer's USB port (see diagram C)
- Note: The USB charger has a RED LED indicator light to indicate it is charging.
3. When the battery is fully charged the charging indicator light will change to green.
4. Average charging time is approximately 80-100 minutes. A fully charged drone can fly for approximately 10 minutes depending on environment and user input.



NOTE: You may purchase additional batteries and chargers at [www.propelrc.com](http://www.propelrc.com).




**IMPORTANT: ALWAYS REMEMBER TO UNPLUG YOUR CHARGING CORD WHEN NOT IN USE!**

## HD VIDEO DRONE+WiFi BATTERY INSTALLATION


1. Slide the fully charged battery into the HD Video Drone+WiFi's battery compartment (see diagram D). The battery is designed to only fit in one-way, with the guide rail on the bottom of battery facing downward.
2. Push the battery all the way in and you will hear a click, the drone's LED lights will light up and begin flashing when you have installed the battery correctly.
3. The HD Video Drone+WiFi has no On/Off switch. The HD Video Drone+WiFi automatically turns on when the battery is installed.
4. Removing the battery: On the underside of the drone body you will see a small battery eject lever. Pull the lever up and the battery will eject about 0.5-1cm (see diagram E). Then you can gently pull out the battery.



## HD VIDEO DRONE+WiFi DIAGRAM



## CONTROLLER DIAGRAM



## WARNING

**DO NOT FLY YOUR+WiFi IN FOUL WEATHER!**



## FLIGHT PREPARATION


- Verify that there are 6 "AA" batteries inside the remote control unit and the HD Video Drone+WiFi has been fully charged.
- Make sure to be in a large open space preferably a field or a park with an open radius of at least 200 feet.
- Make sure to start your drone on a clean flat level surface before take-off.
- **IMPORTANT! Until you have experience in flying your HD Video Drone+WiFi, it is not advised to use in any rate of wind. Wait until a zero wind day or extremely light wind when learning how to fly.**

## SYNCING YOUR HD VIDEO DRONE+WiFi


**Important!** When syncing your HD Video Drone+WiFi with the controller always make sure that the drone is on a flat level surface and that your digital trim settings are in the center position. This insures that the 6 Axis gyro is properly programmed to respond to your trim settings. Your HD Video Drone+WiFi utilizes an automatic 2.4G channel selection system that allows up to 8 people to fly side by side in the same wireless range with no interference.

1. Before starting, make sure that the power switch on your controller is off and the battery is removed from the HD Video Drone+WiFi. Make sure that there are no other 2.4G devices in the area.
2. Insert the battery into the HD Video Drone+WiFi and set it down on a clean flat level surface. The red and white LED lights on top of the drone should begin to flash rapidly for a few seconds then slower.
3. Quickly turn ON the remote and you will hear 2 beeping sound and also notice that the top red LED light on the face of the controller should also be flashing.
4. Push the left control stick all the way up until it stops and then pull it back all the way down to the bottom (see illustration below). When pulling the stick down to the bottom you should hear a high-pitched beep and the lights on both the drone and the controller should stop flashing and become solid. If the lights on both the drone and the controller have stopped flashing and become solid you have successfully synced your HD Video Drone+WiFi and are ready to fly. If the lights on the controller or the drone are still flashing repeat steps 1-4 again.

- **TIP 1: Try not to leave too much time between putting your battery into the drone and turning on the controller or your syncing window will time-out.**
- **TIP 2: Syncing your drone indoors or in the shade will make it easier to see the LED light indicators on both the controller and the drone.**



move the control stick all the way up and all the way down you should hear a beep



the flashing red LED light will become solid when you are synced


## NOW YOU ARE READY TO FLY!

If you have successfully synced your HD Video Drone+WiFi to your controller as explained on page 4 you are now ready to fly. Before beginning to fly your drone you should familiarize yourself with how to start and stop the rotors, how to use your auto land feature and how the controls work so please carefully read and familiarize yourself with various control features explain in the next two pages. Once again as a beginner pilot you should learn how to control your drone in a large open field or park on a day with zero or very light wind. Do not try to fly your HD Video Drone+WiFi too high until you become a more experienced pilot.

### RECOGNIZING THE FRONT & REAR OF THE HD VIDEO DRONE+ WiFi

Even though the HD Video Drone+WiFi has four rotors there is still a front or "forward" facing direction and "rear" or backwards facing direction. The front and forward facing direction of the HD Video Drone+WiFi is the side with two gray blades (see diagram F). The rear or "backward" facing direction of the Quadcopter is the side with two black propellers (see diagram F).


**NOTE:** The front of the Quadcopter also displays WHITE LED light and the back of the Quadcopter displays RED LED lights.



### HOW TO START/STOP ROTORS

Make sure you have properly synced the HD Video Drone+WiFi and the power is on.

- To start and stop the rotors simply move the two control sticks either simultaneously down and to the inside or down and to the outside corners and hold for one second (see illustration below).



*Note: Either position will both start and stop the rotors so use the position you are most comfortable with.*

- Once the rotors begin to spin release the control sticks and they will return to the center position. Now you are ready for take-off.

### SPEED SELECT BUTTON

The HD Video Drone+WiFi has 3 speed settings; SLOW (40%), MEDIUM (70%) and HIGH (100%). The Default setting when you first turn on your HD Video Drone+WiFi is the SLOW (40%) speed mode. To increase the speed simply trigger the Speed setting button (see remote diagram on pg 3) you will hear a beep and the speed setting indicator on screen will show you what speed setting you are on. Speed settings can be set before flight or during the flight.

### AUTO LAND BUTTON

The HD Video Drone+WiFi has an auto land feature which allows you to land automatically. Simply press the Auto Land Button and your HD Video Drone+WiFi will begin land itself.

**Note:** You can still control the direction while auto landing to avoid obstacles.

## 3 CHANNEL VS 4 CHANNEL FLYING

Propels unique "switch-blade" technology allows you to choose between 3ch or 4ch flight control modes. Most people with no experience in flying multi copters may find 3ch easier to learn at first as controls are set up to simply move forward, back, turn left and turn right. 4channel flying gives the operator ultimate control by adding two more dimensions of flight banking left and banking right.

**NOTE:** The HD Video Drone+WiFi's default setting is 4 Channel mode.

### To change to 3 Channel mode:

PRESS and hold the 3/4 CH button (see remote diagram on pg 3), you will hear a beep sound and the screen showing MODE 2 indicating the HD Video Drone+WiFi now is set to 3 CH mode.

### To change back to 4 Channel mode:

PRESS and hold the 3/4 CH button (see remote diagram on pg 3), you will hear a beep sound and the screen showing MODE 1 indicating the HD Video Drone+WiFi is now set to 4 CH mode.


### 3 CHANNEL FLIGHT CONTROL

Below is a list of basic flight functions for your long-range remote to control the HD Video Drone+WiFi.

While learning to fly your HD Video Drone+WiFi it is best to start in a large space until you get used to the basic controls. As you master flying your HD Video Drone+WiFi you can move to more advanced maneuvering techniques. Practice makes perfect! When you have these basic steps down you can move to the next level.


Move the Throttle stick up to increase the propeller speed and the HD Video Drone+WiFi will accelerate and ascend.

Move the Throttle stick down to decrease the propeller speed and the HD Video Drone+WiFi will decelerate and descend (see diagram L).




While in the air, move the Direction Stick up and the HD Video Drone+WiFi will move forward.

Move the Direction Control down and the HD Video Drone+WiFi will move backward (see diagram M).



While in the air, move the Direction Control left and the HD Video Drone+WiFi will spin to the left.

Move the Direction Control right and the HD Video Drone+WiFi will spin to the right (see diagram N).




## 4 CHANNEL FLIGHT CONTROL

Below is a list of basic flight functions for your long-range remote to control the HD Video Drone+WiFi. While learning to fly your HD Video Drone+WiFi it is best to start in a large space until you get used to the basic controls. As you master flying your HD Video Drone+WiFi you can move to more advanced maneuvering techniques. Practice makes perfect!


Move the left Throttle stick up to increase the propeller speed and the HD Video Drone+WiFi will accelerate and ascend.

Move the left Throttle stick down to decrease the propeller speed and the HD Video Drone+WiFi will decelerate and descend (see diagram O).




While in the air, move the left Throttle stick left and the HD Video Drone+WiFi will rotate left.

Move the left Throttle stick right and the HD Video Drone+WiFi will rotate right (see diagram P).




While in the air, move the right Direction Stick up and the HD Video Drone+WiFi will move forward.

Move the right Direction Control down and the HD Video Drone+WiFi will move backward (see diagram Q).




While in the air, move the right Direction Control left and the HD Video Drone+WiFi will bank to the left.

Move the right Direction Control right and the HD Video Drone+WiFi will bank to the right (see diagram R).



## FLIGHT PRACTICE

To master flying your aircraft try practicing the exercises shown below. Start with simple vertical take offs, landings, and left/right turning and rotating. Once those are mastered move on to square and cross maneuvers. Good luck and have fun!



Fixed-point Landing

Square Pattern Maneuver


Cross Pattern Maneuver

## ADJUSTING THE TRIM

NOTE: The HD Video Drone+WiFi is already properly trimmed and calibrated right out of the box and should not require any trim adjustments before flying. Some more experienced pilots may want to adjust trim settings for their style of flying. After several crashes you may need to adjust trim settings for the HD Video Drone+WiFi to be more balanced.


### Forward/Backward Trim

- If your HD Video Drone+WiFi drifts forward, push and release the TRIM button backward repeatedly until the motion stops and proper flight is maintained (see diagram G).
- If your HD Video Drone+WiFi drifts backwards, push and release the TRIM button forward repeatedly until the problem is resolved.




### Right/Left Trim

- If your HD Video Drone+WiFi drifts left, push and release the RIGHT TRIM button rightward repeatedly until the motion stops and proper flight is maintained (see diagram H).
- If your HD Video Drone+WiFi drifts right, push and release the TRIM button repeatedly until the problem is resolved.




### Right/Left Spin Trim

- If your HD Video Drone+WiFi spins counter clockwise, push and release the TRIM button rightward repeatedly until the motion stops and proper flight is maintained (see diagram I).



- If your HD Video Drone+WiFi spins clockwise, push and release the SPIN TRIM button leftward repeatedly until the problem is resolved (see diagram J).




### Throttle Speed Trim

If you find the throttle is too sensitive when you fly the HD Video Drone+WiFi, you may need to utilize the Throttle speed trim.

- Push and release the Throttle speed trim button back to lower the sensitivity of the throttle. Push and release the Throttle speed trim button forward to increase the sensitivity of the throttle (see diagram K).

The middle position is recommended.



NOTE: The use of the Trim buttons utilizes sounds. A single long Beep indicates the product is center trimmed. Press with no Beeps indicate the product is trimmed to the maximum on a particular side.

### CALIBRATING THE HD VIDEO DRONE+WiFi


NOTE: Your HD Video Drone+WiFi comes pre-calibrated out of the box so you are ready to fly.

After several crashes and shock to your gyro sensors, you may notice that your drone is drifting and not holding its center position as well as it used to.

This most likely means that you need to recalibrate the 6 axis gyro. Please follow the simple instructions below.

1. Gently set your HD Video Drone+WiFi on a flat level surface.
2. Make sure the HD Video Drone+WiFi is on and that the controller is synced (refer to syncing pg 4. ). Do not start the blades. Instead move both the throttle and control stick down and to the left corner and hold them there for 5 seconds(See Diagram U). You will see the lights on the drone rapidly flash and stop. Once the lights stop flashing you have completed your calibration and are ready to fly!



**TROUBLE SHOOTING:** If you do not see the lights flash, turn off your controller take out the battery in the Drone and Start again. Always make sure to put your battery in first, then turn on your controller. Push the left throttle stick up all the way and then pull back down again. When you hear the beep the HD Video Drone+WiFi is synced to the controller and you are ready to calibrate.



### HOW TO PERFORM 360° STUNT ROLLS

Performing 360° stunt rolls with the HD Video Drone+WiFi is as easy as 1-2-3:

1. Set the speed settings to 70% or 100%, Hover the HD Video Drone+WiFi in still position making sure that you have at least 5 feet of clearance .above and below the quadcopter.
2. Short press down the stunt button and you will enter the stunt roll mode which is indicated by a rapid beeping (see diagram V1).
3. Determine which direction you want it to flip and quickly push the right control stick in the direction you want to flip your HD Video Drone+WiFi (see diagram V2).
4. To exit the Stunt Roll mode, simply press the stunt button again.



**IMPORTANT NOTE: YOU MUST DEPRESS AND HOLD DOWN THE STUNT BUTTON UNTIL YOU BEGIN TO FLIP.**

## USING YOUR ON-BOARD CAMERA

Your HD Video Drone+WiFi comes equipped with an onboard digital camera that takes still pictures and records video. To enable Using these features, download the free APP on your compatible mobile device. This will also allow you to shoot, record and stream by the on board camera. For more details refer to included LIVE VIDEO STREAMING SETUP GUIDE. Now you can have hours of fun creating aerial photography and videos for family and friends.

### GETTING STARTED

The camera enables recording directly to your mobile device (standard definition) and onto a microSDHC card(High Definition).

Note: You can directly download the Hight Defination videos from the microSDHC card to your compatible mobile device.

### RECORDING TO microSDHC CARD

To use with a microSDHC card you will need:


1. One microSDHC card (not included)
2. One microSDHC card reader (included)
3. A Computer with a USB port and Windows Media Player or other Media player that can play AVI files (not included).

### FORMATTING YOUR microSDHC CARD

Before you can begin to take videos or digital photographs you must first format your microSDHC card. To format your card simply place it into the included USB card reader and plug it into your computer's USB port (See diagram W1 and W2 below). After a few moments an icon will appear on your Desktop. Right click on the icon and follow instructions to format your microSDHC card.

### INSTALLING THE microSDHC CARD IN YOUR HD VIDEO DRONE+WiFi

- Place the formatted microSDHC card into the back of the HD Video Drone+WiFi's digital camera port (see diagram W3 below). Push gently until you hear and feel the microSDHC card "click" into slot.
- Turn the HD Video Drone+WiFi on and make sure that it is both fully charged and properly synced to the Controller (see HOW TO SYNC YOUR QUADROPTER on page 4).



### REMOVING YOUR microSDHC CARD

To remove your microSDHC card push in gently on the back of the card until you hear and feel a "clicking sound". The card will "pop-out" slightly and is ready for removal. Simply grab and pull it gently away from the HD Video Drone+WiFi's camera port. Always store your microSDHC card in a clean, safe and cool environment.

### DOWNLOADING AND CLEARING SPACE ON YOUR microSDHC CARD

Plug your microSDHC card into the card reader and connect to your computer. It is best to always download all your videos and pictures on to your computer and not store this data on your microSDHC card. After downloading your photos and videos, follow your computers instructions to "delete" files on your microSDHC card.

**Note: The HD Video Drone+WiFi can record video files up to 2 minutes of length. When attempting to record longer videos, it will automatically split the video into multiple files, each approximately 2 minutes in length. Still photos and videos are recorded simultaneously on device and microSDHC card.**

#### FCC RF exposure statements

This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body or nearby persons.

#### IC Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

#### Déclaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

## TROUBLESHOOTING YOUR HD VIDEO DRONE+WiFi

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
<b>No Power</b>	<ol style="list-style-type: none"> <li>1. Power switched off</li> <li>2. Polarity is reversed</li> <li>3. Batteries may be low or in need of charging</li> </ol>	<ol style="list-style-type: none"> <li>1. Switch the ON/OFF switch to ON</li> <li>2. Make sure all batteries are installed correctly (see diagram A)</li> <li>3. Replace batteries</li> </ol>
<b>Aircraft Not Responding</b>	<ol style="list-style-type: none"> <li>1. Remote is switched off</li> <li>2. battery power in remote is too weak</li> <li>3. The remote is not properly synced</li> <li>4. Out of control range</li> </ol>	<ol style="list-style-type: none"> <li>1. Switch the ON/OFF switch to ON</li> <li>2. Change batteries in remote</li> <li>3. Re-sync the remote</li> <li>4. Do not fly beyond 400 feet</li> </ol>
<b>Aircraft Won't lift off</b>	<ol style="list-style-type: none"> <li>1. Rotor speed too slow</li> <li>2. Aircraft not fully charged</li> <li>3. Obstruction of rotors</li> </ol>	<ol style="list-style-type: none"> <li>1. Push throttle lever forward</li> <li>2. Recharge your HD Video Drone+WiFi</li> <li>3. Check rotors for hair or other obstructions</li> </ol>
<b>Aircraft Descends Too Fast</b>	Moving the throttle down too quickly flying in high wind or bad weather	Control the throttle slower, use auto land feature, Do not fly in bad weather

If you continue to encounter problems please feel free to call our customers service line at (949) 566-9573 Ext 1 for assistance.


## REPLACING THE PROPELLER BLADES

Your HD Video Drone+WiFi's propeller system is a precision instrument that may need repair or replacement from time to time for optimal flight function. Crash landing at high-speed may cause damage to your HD Video Drone+WiFi's propellers.



1. The HD Video Drone+WiFi has four blades, two gray colors on front, and two black colors on back (see the diagram X).
2. When replacing the propeller blades, make sure to match both the color of the blade and the indication letter on the blade.
3. Replace the damaged blade with the correct blade.

Gray Blade Front Left = B  
 Gray Blade Front Right = A

Black Blade Back Left = A  
 Black Blade Back Right = B



## ATTACHING THE BLADE GUARDS



Your HD Video Drone+WiFi is equipped with 4 blade guards for beginner to fly. These can be easily removed and re-attached when needed. To attach the blade guard, align each guard with the slots on the body near the propeller as shown. Clip the two notches on the inner portion of the blade guards into place on the slots and adjust to ensure they have been locked in securely.

## HD VIDEO DRONE+WiFi WARNING:

The HD Video Drone+WiFi is designed for OUTDOOR use. The HD Video Drone+WiFi's blades revolve at high speeds and can cause damage to the user, spectators and animals. Stand away from the HD Video Drone+WiFi to reduce the risk of getting into the flight path. Warn spectators that you will be flying your HD Video Drone+WiFi so that they are aware of its position. Before flight, inspect the rotor blades to make certain that the blades are securely fastened to the HD Video Drone+WiFi.

### WARNING!

- Choking/Cutting Hazard. Small Parts/Sharp Rotor Blades.
- Keep hands, hair and loose clothing away from the propeller when the battery is plugged into the drone.
- Turn off the transmitter and HD Video Drone+WiFi power switches when not in use.
- The included charger is built specifically for the HD Video Drone+WiFi Li-Poly battery. Do not use it to charge any other battery.
- New alkaline batteries are recommended for maximum performance.
- Parental supervision recommended when flying HD Video Drone+WiFi.

## BATTERY WARNINGS

### RECHARGEABLE BATTERY:

This HD Video Drone+WiFi uses a Li-Poly rechargeable battery. If the battery can no longer be charged, dispose it properly according to local disposal requirements.

### CONTROLLER BATTERIES:

- Remote control requires 6 "AA" batteries (not included). Please read the important battery safety warning below.
- Do not mix alkaline, standard (carbon-zinc) and rechargeable batteries (Nickel Metal Hydride).
  - Do not mix old and new batteries.
  - Non-rechargeable batteries are not to be recharged.
  - Rechargeable batteries are to be removed from the item before being charged (if removable).
  - Rechargeable batteries are only to be charged under adult supervision.
  - Exhausted batteries should be removed immediately and must be recycled or disposed of properly according to state or local government ordinances and regulations.
  - The supply terminals are not to be short-circuited.
  - Only batteries of the same or equivalent type as recommended are to be used.
  - Batteries are to be inserted with the correct polarity (see inside booklet for diagram).
  - Do not dispose batteries in a fire - batteries may leak or explode.

## CARE AND MAINTENANCE

- Always remove the batteries from the wireless remote control when it is not being used for an extended period of time.
- To clean, gently wipe the remote control and HD Video Drone+WiFi with a clean damp cloth.
- Keep the toy away from direct heat or sunlight.
- Do not submerge the toy into water. This can damage the unit beyond repair.
- Parental guidance recommended when installing or replacing the batteries.